

IMPORTANT GROUND WIRE INSTALLATION

The purpose of this installation sheet is to instruct the user on installing a ground wire to the S2 terminal in the wiring base. S2 must be grounded for use with the 70D40 or 70D41 when using the 72DIR1, 72DIR3 or 72DIR3T infrared AUTOCHECK amplifier. Kit 129-157 supplies the necessary parts to accomplish this.

Referring to the figure of the wiring base below, insure that all AC power is removed.

1. Remove screw, Item 1, that fastens the terminal block, Item 2 to the wiring base and discard.
2. Remove screw, Item 3 from terminal S2 and place to one side for later re-installation.
3. From Kit 129-157, insert supplied screw (#8-32 x 9/16") into the ground wire loop.
4. Position assembly over S2 terminal so that it aligns with the terminal block and the wiring base.
5. Secure kit-supplied screw and ground wire through the terminal block into wiring base.
6. Insert screw from S2 terminal into ground wire and install into S2 terminal.

