

Wiring Cross Reference

HONEYWELL CB70
TO E110, ED510, EP160, 60-1386-2.
Refer to Amplifier and Scanner Reference Guide

Honeywell	Function	Fireye	
L1	Hot – 120 VAC	L1	
L2	Ground – Neutral	L2	
F	Scanner	S1	
G	Scanner	S2	
L1 – 4	Operating Control	L1 – 13	See Note 1
L1 – 3	Pre-Ignition Interlocks Fuel Valve Interlock	13 – 3	See Note 1
4 – 12	Running Interlocks (Air Flow Switch)	3 – P	See Note 1
5	10 Sec – Interrupted Pilot	5	
6	15 Sec – Interrupted Pilot	6	
7	Main Fuel Valve	7	
8	Blower Motor	M	
L1 – 14	Low Fire Start Switch	M – D	See Note 1
L1 – 15	High Fire Start Switch	D – 8	See Note 1
9	Alarm	A	
Modulation Circuit			
13	High Fire	X	
10	Common	10	
11	Auto	11	
16	Low Fire	12	

Note 1 Identify and isolate indicated switches and rewire to appropriate Fireye terminals.

Refer to Bulletin E-1101 for proper installation, grounding, operational and safety checkout procedures. Perform safety checks of the entire system prior to allowing fuel entry into boiler. Complete safety checks, flame signal levels, minimum pilot tests with fuel on.